

## **P227**

# FREEZER CLEANER ALL PURPOSE CLEANER

#### **DIRECTIONS:**

Some individuals may be sensitive to ingredients in this product. Before use, read product label and SDS sheet. If questions remain, consult your employer or a physician. Do not mix with chemicals not specified on the product label. In concentrate, Freezer Cleaner FP is suitable for use at temperatures down to -20°F. In less extreme environments, better economies can be obtained by diluting Freezer Cleaner FP. At a two-parts Freezer Cleaner FP - to - onepart water (2:1) dilution ratio it can be used down to -20°F. A 1:1 dilution is suitable for temperatures down to 0oF. Do not rinse. Remove soiled solution with wet vac, squeegee or dry cloth. Do not use on food contact surfaces. Automatic Scrubbers: Fill tank with properly diluted product. Lay down solution with scrubbing action. Allow solution to remain on surface for 5 minutes. Rescrub. Rotary Floor Machine: Apply solution by spray or mop and let soak for five minutes. Scrub well. Manual Cleaning: Apply cleaner by spray, mop or sponge. Follow with aggressive double brushing or scrubbing.

#### PRECAUTIONARY STATEMENTS:

Keep away from open flames. No smoking. Keep container tightly closed. Take precautionary measures against static discharge. Wear gloves and protective eyewear. If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water/ shower. In case of fire: Use dry extinguishing powder, foam to extinguish. Store in a well-ventilated place. Keep cool. Dispose of contents/container in accordance with local/regional/national/ international regulations.

#### PHYSICIAL PROPERTIES

APPEARANCE: Red liquid

Specific Gravity: 0.88

Odor: Light solvent

pH: 10

Solubility in water:: n/a use undiluted

#### **PACKAGING**

Stocked in gallons and pails.

Other sizes available.
Call for minimums



### CleanPak Products LLC.

221 Hobbs St. Suite 108 Tampa, FL 33619 T 813-740-8611 - F 813-740-8218 www.cleanpakproducts.com